

Operating instructions

Heater GP 14



Translation from the German
© 2013 Elster-Instromet B.V.

Contents

Heater GP 14	1
Contents	1
Safety	1
Checking the usage	2
Type code	2
Part designations	2
Type label	2
Installation	2
Tightness test	3
Removing the protective cap (optional)	3
Wiring	3
Connecting the room thermostat for "Heating" and "Controlled air flow" mode	4
Connecting multiple heaters to a single room thermostat	5
Reset, alarm, external fan	5
Adjusting the switch-on delay t_E	5
Commissioning	6
Adjusting the heater	6
Installing the protective cap	7
Cleaning	8
Assistance in the event of malfunction	9
Maintenance	12
Checking the safety functions and burner operation	13
Accessories	13
Spare parts	15
Technical data	16
Declaration of conformity	16
Goods return form	17
Contact	18

Safety

Please read and keep in a safe place



Please read through these instructions carefully before installing or operating. Following the installation, pass the instructions on to the operator. This unit must be installed and commissioned in accordance with the regulations and standards in force. These instructions can also be found at www.docuthek.com.

Explanation of symbols

1, 2, 3... = Action
 > = Instruction

Liability

We will not be held liable for damage resulting from non-observance of the instructions and non-compliant use.

Safety instructions

Information that is relevant for safety is indicated in the instructions as follows:

DANGER

Indicates potentially fatal situations.

WARNING

Indicates possible danger to life and limb.

! CAUTION

Indicates possible material damage.

Maintenance and repairs may only be carried out by qualified gas technicians and electrical interventions may only be carried out by qualified electricians.

Conversion, spare parts

All technical changes are prohibited. Only use OEM spare parts.

Transport

On receipt of the product, check that the delivery is complete (see page 2 (Part designations)). Report any transport damage immediately.

Storage

Store the product in a dry place. Ambient temperature: see page 17 (Technical data).

Changes to edition 11.12

The following chapters have been changed:

- Checking the usage
- Installation
- Accessories
- Technical data
- Contact

Checking the usage

GP 14

Heater with direct, open combustion for agricultural stables and horticultural greenhouses. Depending on the type and setting, the heater can be operated with natural gas or LPG (propane/butane).


This function is only guaranteed when used within the specified limits – see page 16 (Technical data).

Any other use is considered as non-compliant.

Type code

Code	Description
GP	Heater
14	Capacity 14 kW, jet length 10 m

Part designations



- 1** Burner control unit BCU
- 2** Gas combination control CG 10
- 3** Vane
- 4** Mixer pipe
- 5** Assembly accessories
- 6** Protective cap for use in agriculture (option)

Type label

Air circulation, electrical connection rating, voltage, rated heat input, gas type, category, supply pressure, burner pressure, enclosure: see type label.



- Before installation, check whether the device is suitable for the regional gas type and the specified limits, see type code and page 16 (Technical data).

Installation

⚠ DANGER


Danger of death! Gases are generated during the storage of slurry which remain partly dissolved in the liquid. If the slurry is strongly agitated during mixing and purging, poisonous, explosive gases such as hydrogen sulphide and methane are released. If an ignition source is present, the released gas can explode.

To avoid damage during operation, please observe the following:

- Switch off the heater before mixing and purging the slurry.
- Close the slide valves when storing slurry outside.
- The fan for the air supply must not be part of a closed pipe system.
- The space to be heated must be adequately ventilated.
- For mechanical extraction equipment: at least 10 m³/h of air per installed capacity.
- In the case of natural ventilation, the structure must have two apertures with a free opening area of 60 x B in cm². "B" is the installed capacity in kW. Replacement of the full air volume per hour is thus ensured.
- In the case of natural ventilation, the maximum allowable total capacity of the heater is 1 kW per 20 m³ of volume.
- Respect the safety distance of the heater to inflammable materials, see "Installation position".
- Consult your fire insurance provider and/or local fire protection engineer to assess the foreseeable, general risk of fire.
- For cleaning, care and maintenance, note the applicable national regulations and directives.
- No condensation permitted. Check the ambient temperature, see page 16 (Technical data).

Installation position

- ▷ To ensure that the vane functions faultlessly, install the unit in the horizontal position.
- ▷ Note the safety distance to walls and inflammable materials.




- ▷ Ensure sufficient free space around the device. There must be no obstructions in front of the inlet and outlet side of the heater.
- ▷ To avoid overheating, do not cover the electric motor.

Connecting the gas supply

- ▷ If the heater is suspended on chains, use an approved flexible gas hose.
- 1** Disconnect the system from the electrical power supply.
- 2** Shut off the gas supply.
- 3** Remove the screw plug at the inlet of the gas combination control CG.
- 4** Connect the gas pipe with threaded connection R ½" or gas hose, see page 13 (Accessories), to the inlet of the gas combination control.
- ▷ Use approved sealing material only.
- ▷ Note the maximum inlet pressure, see page 16 (Technical data).

Tightness test

- ▷ The system is disconnected from the electrical power supply. The valves are thus closed.




Removing the protective cap (optional)


- ▷ For agricultural use, the burner control unit and vane switch are mostly protected against ingress of dirt and moisture by a cap.
- ▷ To wire the burner control unit and to start and adjust the heater, the protective cap is to be removed as described below.
- ▷ Do not remove the protective cap on the vane switch.

Burner control unit


- 1** Slowly pull apart the ends of the protective cap on the back of the burner control unit until the rivets come undone.



- 2** Pull the opened edges of the protective cap out fully so that the edges are pulled out from between the burner control unit and the mounting plate.



- 3** Remove the opened protective cap from the burner control unit by pulling it upwards.




Wiring

! CAUTION

Danger of electric shocks!

- Before working on possible live components, ensure the unit is disconnected from the power supply.
- 1** Disconnect the system from the electrical power supply. The mains plug may only be pulled out once the device has been switched off.
- 2** Shut off the gas supply.
- ▷ If there is a protective cap on the burner control unit, this must first be removed.
- ▷ When opening the burner control unit, do not incline the upper housing section during its removal to prevent the plug connectors from being bent.





BCU 300:THP-G

The diagram illustrates the internal wiring of the BCU 300:THP-G control unit. It features a main terminal block on the left (terminals 1-16) and a PE terminal block at the top. The unit is designed for AC/DC 24V operation, with a maximum current of 2A for 253V and 5A for 253V. Key components include a fuse F1 (8A) and a fuse F2 (3,15A) on the input side, a thermal relay (WF) for motor protection, a contactor (C) for switching, and a thermal relay (V2) for motor protection. The diagram also shows the connection of the unit to a power source (L1, L2, PE) and a motor (M).

F1 T 8A H

F2 T 3,15A H
IEC 60127-2/5


L1 (L1)
N (L2)
PE

- 5** Connect the terminals for Controlled air flow  and Heating .


- GB-4

Connecting multiple heaters to a single room thermostat


- ▷ Phase reversal will result in a short-circuit.
- ▷ Do not install different phases of a three-phase current system at the inputs if the voltage between the phases exceeds 230 V (+ 10%).
- ▷ Multiple heaters must be wired to the thermostat via a relay.



- ▷ At 24 V DC/AC, multiple heaters can be controlled in parallel.
- ▷ Note the polarity!




- ▷ Do not directly connect the thermostat to multiple heaters.
- ▷ Do not connect terminals 28, 29 and 30 directly to the next heater. A short-circuit can occur due to different phases and polarities.




Reset, alarm, external fan

- ▷ For external fault signalling, an external alarm and an external reset button can be connected.




- For improved air circulation in the room, an additional fan can be connected.




- ▷ In case of a power failure, an emergency power supply unit should automatically take over the power supply. Emergency power supply units with a cardan shaft drive for tractor attachment are also suitable.

Adjusting the switch-on delay t_E

- ▷ If multiple heaters switch on at the same time, there can be a gas and/or power shortage on individual devices. To avoid this happening, adjust the switch-on delay t_E using the potentiometer in the upper housing section of burner control unit BCU.
- ▷ The potentiometer is set to 0 s at the factory.



- ▷ We recommend using a switch-on delay t_E of 5 to 10 s between each device.
- ▷ The post-cooling time t_N is set to 50 s at the factory and the minimum burner on time t_M to 0 s. These values must not be changed.
- ▷ Once the wiring is complete, close the BCU again. Ensure that the upper housing section is not inclined when being replaced on the lower housing section.



- ▷ To guarantee that the burner control unit complies with enclosure IP 54, make sure that the screws are tightly secured after wiring and that the cable glands are closed.
- 10** Switch on the power supply.
- 11** Release the gas supply.


Commissioning

- ▷ The heater may only be commissioned once it has been ensured that the heater, gas pipes, mains voltage supply and room thermostat have been installed by authorized, trained personnel according to the regulations.

1 Switch on the power supply.

2 Release the gas supply.

Part designations




1 MODE/RESET selection button






2 BCU On/Off switch

3 Red lamp lights up if a fault is pending


4 Operating mode LED: Off

5 LEDs for selectable operating modes

- ▷ The BCU is operated using two buttons: using the ON/OFF button , the heater is switched on and off. By pressing the MODE selection button for > 1 s, it is possible to switch between the different operating modes.


Operating mode	Explanation
AUTO 	BCU waits for the signals for controlled air flow or heating.
	Heating (continuous operation)
	Controlled air flow (continuous operation)
 + AUTO 	Controlled air flow (continuous operation) and heating when thermostat signal is applied

Switching on


3 Switch on the burner control unit. Press ON/OFF  until an LED lights up.

- ▷ The BCU switches on in the last operating mode selected.
- ▷ The heater starts once the set switch-on delay time t_E has elapsed, see page 5 (Adjusting the switch-on delay t_E).
- ▷ The burner starts after the safety time of 5 s has elapsed and operates in the selected operating mode.
- ▷ The operating mode can be changed using the MODE selection button. The selected operating mode is only activated once the device has been in this position for at least 3 s. It is thus possible to "scroll" through the different operating modes.

Switching off

- 4** Switch off the heater. Press ON/OFF . The LED next to "OFF" lights up and the burner switches off after 3 s. Mains voltage is still supplied however.
- ▷ The fan cools the heater down until it reaches switch-off temperature.

Faults

- ▷ Flashing LEDs signal the cause of a fault, see page 9 (Assistance in the event of malfunction).
- ▷ In the first 4 s after switching on the power supply or pressing the ON/OFF button , an operating mode is not yet active. Within these 4 s, a new operating mode can be selected. As soon as the MODE selection button has been pressed and a new operating mode has been selected, the 4 s are extended accordingly.
- ▷ If a fault has occurred, it is displayed immediately, but 4 s are also available here during which a new operating mode can be selected.


Adjusting the heater

Burner gas pressure p_G

p_U = Inlet pressure

p_G = Gas pressure on the burner

- ▷ Inlet pressure p_U and gas pressure p_G can be measured using the pressure test points on the combination control.



- ▷ Use a 2.5 mm Allen key for adjustment. Do not use force!
- ▷ The gas/outlet pressure p_G must be measured on the combination control for adjustment.

1 Disconnect the system from the electrical power supply. The mains plug may only be pulled out once the device has been switched off and post-cooling is complete.

2 Shut off the gas supply.


3 Open measuring nipple p_G .


4 Connect a pressure gauge with display range 10 to 50 mbar to p_G .

5 Switch on the power supply.

6 Release the gas supply.

- ▷ The inlet pressure p_U must comply with the technical data, see page 16 (Technical data).

7 Switch on the burner control unit. Press the ON/OFF button  until an LED lights up.

8 Select the Heating  operating mode.

9 Let all heaters burn for at least 20 s.

- ▷ The required gas pressure on the burner depends on the lower calorific value/Wobbe index.

- 10** Select the required gas pressure on the burner from the table.

	Lower calorific value [MJ/m ³]	Wobbe index [MJ/m ³]	[mbar]
Natural gas L G 25	32.49	41.53	12.5
Natural gas H G 20	37.78	50.71	8,0
LPG G 30	125.81	87.34	28.0


- ▷ Converting the lower calorific value/Wobbe index to kWh/m³:

$$\text{kWh/m}^3 = \frac{\text{Lower calorific value/Wobbe index [MJ/m}^3\text{]}}{3.6}$$


- ▷ Always use a pressure gauge to adjust the burner gas pressure. The white scale on the adjusting screw may differ.

- 11** If all heaters are heating at the same time, compare the required gas pressure on the burner with the gas pressure p_G read off the pressure gauge.

- 12** Monitor the pressure gauge and set the gas pressure p_G . 1 turn = approx. 1.3 mbar.



- ▷ All heaters must be operating for this adjustment.
▷ Do not change the flow adjustment. It is set to fully open at the factory.



Flame signal

- ▷ The flame signal is displayed for 20 s.

- 13** Check the flame signal.

- ▷ For adjustment and maintenance work, the flame signal can be displayed.
▷ Display of the flame signal starts when the selection button is pressed and within 1 s (almost simultaneously), ON/OFF is pressed, too.

● = LED is constantly lit

○ = LED flashes

		2	3	4	6	8	10	12	14	16	18	20
OFF	○ 1										○	●
AUTO	○ 2									○	●	●
	○ 3						○	●	●	●	●	●
	○ 4			○	●	●	●	●	●	●	●	●
⊕ + AUTO	○ 5	○	●	●	●	●	●	●	●	●	●	●

- ▷ The flame signal is sufficient when 2 LEDs are constantly lit and the third LED flashes.

- ▷ If the flame signal is not sufficient, see page 9 (Assistance in the event of malfunction).

- 14** Monitor combustion.

- ▷ The flame must be blue and must remain inside the device.

- ▷ If the burner pressure p_G and flame signal have been checked and adjusted on all devices, the system operates correctly.

- 15** Remove the pressure gauge.

- 16** Close the test nipple.


Installing the protective cap

Burner control unit

- 1** Pull the opened protective cap from the top over the burner control unit. In doing so, pull the edges of the protective cap apart.



- 2** Slide the opened edges of the protective cap into the gap between the burner control unit and the mounting plate.



- ▷ When it becomes difficult to move the edges of the protective cap, this means the material has turned cold and hard. The protective cap will become soft again when it is heated briefly.

- 3** Hold the ends of the protective cap on the back of the burner control unit together and close the push-in rivets.



! CAUTION

To ensure that no damage occurs during operation and cleaning, please observe the following instructions. Otherwise, injuries or damage to the device may occur and/or the function of the device may be impaired, and the manufacturer's warranty will be cancelled.


- Sharp-edged metal sheets. Always wear protective gloves.
- After cleaning, check that the components on and in the heater are in good condition. The device may only be restarted if all safety devices have been installed and the safety functions have been checked.
- Clean the heater once a year when used in horticulture and at regular intervals as well as after each fattening period when used in agriculture, as described below. Inadequate or irregular cleaning can cause damage to the device or lead to fire damage. For example, dirt particles can catch fire and can be blown out of the device.

1 Switch off the burner control unit BCU.

2 Disconnect the system from the electrical power supply. The mains plug may only be pulled out once the device has been switched off and post-cooling is complete.

3 Shut off the gas supply.


- ▷ If the burner control unit is not equipped with a protective cap, we recommend cleaning the heater with compressed air or a damp cloth only.
- ▷ Equipping the burner control unit BCU with a protective cap allows the BCU to be cleaned carefully with a water jet/high-pressure cleaner during cleaning/disinfection of the animal shed.
- ▷ To guarantee that the burner control unit complies with enclosure IP 54, make sure that the screws are tightly secured after wiring and that the cable glands are closed.
- ▷ The distance between the nozzle and the surface to be cleaned must always be at least 50 cm.




- ▷ Do not direct the water jet straight at the combination control and electrical components such as the vane.
- ▷ The water jet from the high-pressure cleaner can cause serious damage to the components in the heater. For example, the vane can be bent

or other parts such as the spark plug or rubber seals can be displaced. Avoid direct contact.


- ▷ Do not spray the edges of the protective cap which are closed using push-in rivets only or the connection between the burner control unit and the mounting plate directly with water, high-pressure cleaning equipment or chemical cleaning agents.



- ▷ Do not spray water or chemical cleaning agents directly into the space between the fan shaft/impeller wheel and motor and do not clean with high-pressure cleaners.




- ▷ Chemical cleaning agents, disinfectants and/or pesticides contain corrosive substances which can even corrode stainless steel. Always rinse the devices with water after cleaning using such agents to remove any residue of these agents from the surface.




6 Clean the grille.

7 Clean the fan and vane using a cloth.




- 8** Clean the interior of the device carefully using air or clean the plates for the air intake and the burner head using a cloth.




- ▷ The vane must not be bent.


- 9** Check that the vane switch is functional.
- ▷ If the vane is moved a little in the direction of the arrow, a quiet click can be heard. This means that the switching path is correct.




- 10** Check the mixer pipe for dirt. Clean the opening using a cloth.



Assembly



- ▷ Check the burner is functioning faultlessly in normal operation, see page 13 (Checking the safety functions and burner operation).
- 13** When operating with propane, check that the breather orifice of the pressure reducer on the connection kit is clean.



Assistance in the event of malfunction

⚠ WARNING

To avoid harm to persons and animals or damage to the heater, please observe the following:

- Electric shocks can be fatal! Before working on possible live components, ensure the unit is disconnected from the power supply.
- Fault-clearance must only be undertaken by authorized, trained personnel!
- Repairs to components, e.g. the burner control unit BCU or the combination control CG, may only be carried out by the manufacturer. Otherwise, the guarantee will be cancelled. Unauthorized repairs or incorrect electrical connections, e.g. the connection of power to outputs, can cause gas valves to open and the burner control unit to become defective. In this case, fail-safe operation can no longer be guaranteed.
- (Remote) resets may only be conducted by authorized personnel with continuous monitoring of the devices concerned.


- ▷ In the event of an installation fault, the burner control unit closes the gas valves and the red LED on the burner control unit lights up. Then, the fault is indicated by a combination of flashing yellow LEDs which are numbered from 1 to 5.
- ▷ Faults may be cleared only using the remedies described below.

- 1** Press the reset button on the BCU to reset it. The unit then reverts to the last operating mode selected.
- ▷ Faults marked with an * are warnings. Provided that a restart has been programmed, they are no longer displayed if the cause of the fault has been remedied. It is not necessary to press the reset button when these messages are displayed.
- 2** If the burner control unit does not respond even though all faults have been remedied, remove the unit and return it to the supplier.

- ? Fault**
- ! Cause**
- Remedy**

Possible faults and suggested solutions


? LED 1 flashes.



- !** Fuse F2 defective.


- Replace fuse (3.15 A, slow-acting, H). Ensure that only one heater is directly wired to the thermostat, see page 3 (Wiring).
- ! Bridge between terminals 9 and 10 is interrupted.
- Check the wiring.

? LED 2 flashes.




- ! Vane switch does not switch off during the “no flow” state check on burner start-up.
- Check that the vane switch is functional, see page 12 (Maintenance).

? LED 3 flashes.



- ! The vane switch has not switched on 25 s after the fan has been switched on.
- Vane, fan or grille are dirty. Clean, see page 12 (Maintenance).
- Fuse F1 defective (8 A, slow-acting, H). Check the function of the fan and replace fuse F1 if necessary.
- ! Motor defective.
- Remove the device and return it to the supplier.

? LED 4 flashes.*



- ! On burner start-up, the BCU has not detected a flame during the safety time. In the parameter “Number of start-up attempts”, it is possible to program up to three start-up attempts. If one of the further start-up attempts is successful, fault signalling stops automatically once the post-purge time has elapsed.
- Ignition is not working properly.
Clean the ignition electrode and check for correct distance, see page 12 (Maintenance).
Check the connection of the ignition cables for damage or moisture. The spark plug must be fitted correctly.
Check the ignition spark optically and acoustically from the fan side during the 4-second ignition time.


- Poor flame signal due to incorrect burner adjustment. Readjust gas pressure p_G , see page 6 (Adjusting the heater).
- Poor flame signal due to dirty/badly connected ionization electrode.
Clean the ionization electrode and check for correct distance, see page 12 (Maintenance).
Check the cable connection, cable and plug for damage or moisture. The plug must be fitted correctly.
Check the yellow and green burner ground cable for corrosion and to ensure it is firmly connected.
- Air in the gas pipe. Vent the gas pipe.

- Valves do not open. Remove the valve plug on the combination control CG and measure the voltage between L1 and N during the safety time. If the voltage is not adequate, first replace the CG and return it to the supplier.

Attention! Only commission the new BCU once the short-circuit or fault on the valve output of the CG has been remedied. Otherwise, the new BCU will be damaged.


- If the fault continues to be signalled, there may be a short-circuit on the valve output. Return the burner control unit to the manufacturer for inspection.
- Short-circuit on ignition output. Replace fine-wire fuse F2: 3.15 A (slow-acting, H) and check the safety function, see page 13 (Checking the safety functions and burner operation).

? LED 5 flashes.




- ! Signal from safety temperature limiter (STL). Temperature has been exceeded.
- No fan run-on due to soiling. Clean, see page 12 (Maintenance).
- ! Fan defective.
- Check function of fan.

? LEDs 4 and 5 flash.*




- ! Signal from safety temperature monitor (STM). Temperature has been exceeded.
- Leave heater to cool down for longer.
- No fan run-on due to soiling. Clean, see page 12 (Maintenance).

? LEDs 2 and 5 flash.




- ! Incorrect flame signal through conductive ceramic insulation, e.g. surge via PE wire, possible.
- Remedy incorrect flame signal. Replace ionization electrode and, if necessary, the BCU as well.

? LEDs 1 and 5 flash.*




- ! Temperature sensor is not functioning correctly.
- Check the temperature sensor connection.
- Temperature sensor is below -20°C.
- ! Temperature sensor defective.
- Replace the temperature sensor.

? LEDs 3 and 4 flash.*



- ! The time (cycle lock) between two starts is too short.
- The BCU ensures there is a pause of 15 s between the starts. This warning is displayed during this time.


? LEDs 2 and 4 flash.*



- ! The flame has gone out during operation. If a restart has been programmed, an automatic restart is carried out provided that the burner has been in operation for at least 2 s beforehand.
- Poor flame signal due to incorrect burner adjustment. Readjust gas pressure p_G , see page 6 (Adjusting the heater).
- Poor flame signal due to dirty or badly connected ionization electrode. Clean the ionization electrode and check for correct distance, see page 12 (Maintenance).
- Check the cable connection for damage or moisture. The plug must be fitted correctly.


- Check the yellow and green burner ground cable for corrosion and to ensure it is firmly connected.

? LEDs 1 and 4 flash.*




- ! A signal is applied for longer than 10 s to the remote reset input (terminals 31 and 32) (permanent remote reset).
- Remote reset must only be used to reset the device.

? LEDs 1 and 3 flash.




- ! The flame has not gone out within 5 s of the burner being switched off. The gas valve does not close correctly.
- Shut off the gas supply to the device. Check the burner and gas valves for correct function, see page 13 (Checking the safety functions and burner operation).

? LEDs 1 and 2 flash.*



- ! The power supply has suffered a fault.
- Ensure there is sufficient mains voltage, see page 16 (Technical data).

? LEDs 3, 4 and 5 flash.



- ! While a fault was pending, more than 5 attempts were made within 15 minutes to reset the device using the remote reset input (terminals 31 and 32).
- Reset is only possible using the reset button on the BCU.


Maintenance

! CAUTION

To ensure that no damage occurs during operation and maintenance, please observe the following instructions. Otherwise, injuries or damage to the device may occur and/or the function of the device may be impaired. The supplier/manufacturer cannot accept liability for damage resulting thereof.


- Have the heater cleaned at least once a year by qualified maintenance personnel.
- Have the safety functions checked at least once a year by qualified maintenance personnel, see page 13 (Checking the safety functions and burner operation).
- Sharp-edged metal sheets. Always wear protective gloves.
- After cleaning or repair work, check that the components on and in the heater are in good condition. The device may only be restarted if all safety devices have been installed and the safety functions have been checked, see page 13 (Checking the safety functions and burner operation).

- 1** Switch off the burner control unit BCU.
- 2** Disconnect the system from the electrical power supply. The mains plug may only be pulled out once the device has been switched off and post-cooling is complete.
- 3** Shut off the gas supply.




- 6** Clean the grille with a cloth.
 - 7** Clean the interior of the device carefully using air.
- ▷ The vane must not be bent.


- 8** Clean the fan and vane using a cloth.




- 9** Check that the vane switch is functional.
- ▷ If the vane is moved a little in the direction of the arrow, a quiet click can be heard. This means that the switching path is correct.




- 10** Check the mixer pipe for dirt. Clean the opening using a cloth.



- ▷ The ionization electrode **I** and ignition electrode **Z** can be removed without having to dismantle the burner chamber.




- 17** Check the electrodes for dirt and if necessary, clean using a cloth. Remove stubborn dirt on the electrode rod using fine abrasive paper.




- 18** Check electrode and porcelain insulator for cracks and replace the electrode in case of damage.


- ▷ Replace the electrodes if necessary.
- ▷ Fit the electrode seal.

- 19** Clean both sides of the plates for the air intake as well as the burner head using a cloth.




Ensure that the rubber seals between the electrodes and the electrode plugs are fitted correctly.





- ▷ The device may only be restarted if all safety devices have been installed.



- 28** Check the safety functions before commissioning, see page 13 (Checking the safety functions and burner operation).

Checking the safety functions and burner operation

⚠ WARNING

If these checks are not carried out, the gas valves might remain open allowing non-combusted gas to escape. Risk of explosion!

Safety functions

- 1** Switch off the heater during operation. Press ON/OFF .
 - ▷ The flame goes out < 1 s.
 - ▷ The fan cools the heater down until it reaches switch-off temperature.
- 2** Remove the valve plug on the combination control during operation.
 - ▷ The gas valves close < 1 s.
 - ▷ The flame goes out.
 - ▷ The burner control unit BCU displays the fault message "The flame has gone out during operation". LEDs 2 and 4 flash.
 - ▷ If a restart has been programmed, the burner control unit will initially attempt to restart and will then perform a fault lock-out. LED 4 flashes and displays the fault message "No flame has been detected during the safety time".
- 3** Shut off the inlet pressure during operation.
 - ▷ The burner control unit performs a safety shut-down: the gas valves are disconnected from the electrical power supply.
 - ▷ The flame goes out.
 - ▷ The burner control unit BCU displays the fault message "The flame has gone out during operation". LEDs 2 and 4 flash.

- ▷ If the burner control unit responds in a different way to that described, a fault has occurred, see page 9 (Assistance in the event of malfunction).

! CAUTION

The fault must be remedied before the system may be operated.


Checking burner operation

- 1** Switch on the BCU.
- 2** Select the Heating operating mode.
- 3** Allow the burner to burn for 15 minutes.
- 4** During this time, monitor the flame pattern.
 - ▷ The flame must be blue.
 - ▷ No dirt particles must come out of the heater.

Accessories

Room thermostat


Use a room thermostat with a hysteresis of $\pm 1^\circ\text{C}$, 230 V, Type TH 215.



Order No.: N50260145


Pressure reducer

Pressure reducer for LPG.



RECA 1.5 bar to 50 mbar, 2 x 1/2" internal thread connection, 10 kg/h, Order No.: N52600023.

Manual valve



2 x 1/2" internal thread connection,


Order No.: N50260019.

1/2" internal and external thread connection,

Order No.: N50260027.


Connection kit for natural gas

Manual valve and gas hose to connect the gas combination control CG to the gas supply.




Connection kit: R 1/2" threaded connection, total length = 1.50 m, Order No.: N52600073

Connection kit for propane




Pressure reducer, manual valve, hose (length = 2 m), 2 hose clamps, R 1/2" double nipple for GP 14/GP 40, to connect the gas combination control CG to the gas supply, Order No.: N52600025



Manual valve and hose (DVGW certified, length = 2 m) to connect the gas combination control CG to the gas supply, Order No.: N52990209

Spare parts

- ▷ When ordering spare parts, please quote the order number along with the designation and item no. of the spare part as well as the heater serial number.
- ▷ When ordering spare parts which are not listed here below, please quote the edition of these operating instructions and the heater serial number.
- ▷ Use original spare parts only to ensure the replacement complies with the requirements stipulated by the manufacturer.



Item	Order No.	Designation
1	N50500022	Fan for GP 14, A4E-300-AA01-02
2	N50500190	Carry handle for GP 14
3	N50500004	GP 14 housing, stainless steel
4	N50260097	Temperature sensor for STM/STL, 6 mm x 45 mm, L = 290 mm
5	N50500161	Burner head for GP 14
6	N50500170	Burner ring for GP 14
7	N50500162	Burner baffle plate for GP 14
8	N50500185	Burner chamber for GP 14
9	N50500220	Mixer pipe mounting ring for GP 14
10	N50500210	Mixer pipe for GP 14
11	N50500230	Natural gas nozzle for GP 14, 12 x 3.30 mm
12	N50500240	LPG nozzle for GP 14, 6 x 1.90 mm
13	N50500215	Nipple
14	N50290025	90° male/female elbow, galvanized, Rp 1/2"/R 3/4"
15	N50500063	Gas combination control CG 10 for GP 14/GP 40, Kromschroder CG 10R70-D15WB
16	N50500062	Combination control bracket for GP 14
17	N50260101	BCU 300 upper housing section, incl. electronics, Kromschroder THP-GW 84636001
18	N50260102	BCU 300 lower housing section, incl. ignition transformer
19	N50260144	GP series Ignition transformer, Eichhof E4718/55, gas, 1-pin
20	N50500052	Beru ignition electrode for GP 14
21	N50500090	Ignition cable kit for GP 14, complete with plug and cap
22	N50700901	1" elbow No. 90
23	N50500003	Beru ZE14 ionization electrode for GP 14
24	N50500075	Vane switch, complete, for GP 14-120
25	N50260147	Stand for GP 14
26	N50260097	Safety grille for GP 14, 09534-2-4039-300
27	N50260109	Protective cap for BCU, PVC, black, with viewing window

Technical data

Inlet pressure p_{Li} :

natural gas: 20–25 mbar,

propane: 35–70 mbar.

Gas connection: Rp 1/2" internal thread.

Material:

casing: stainless steel 430,

burner chamber: stainless steel 430,

BCU: PPE.

Ambient temperature:

-10 to +60°C. No condensation permitted.

Cycle lock: 15 s.

Capacity: 14 kW.

Gas consumption:

natural gas L: $\pm 1.5 \text{ m}^3/\text{h}$,

natural gas H: $\pm 1.3 \text{ m}^3/\text{h}$,

propane: $\pm 1.1 \text{ kg/h}$.

Connection rating: 230 V, 50 Hz, 80 W.

Power consumption: I_A/I_N : $\pm 0.8 \text{ A}/0.38 \text{ A}$.

Air circulation:

controlled air flow: $\pm 1000 \text{ m}^3/\text{h}$,

heating: $\pm 1200 \text{ m}^3/\text{h}$.

Jet length: $\pm 10 \text{ m}$.

Housing:

length: 600 mm,

width (total): 420 mm,

height/diameter: 400 mm,

weight: 13 kg.

Declaration of conformity



We, the manufacturer, hereby declare that the product GP complies with the requirements of the listed Directives and Standards.

Directives:

- 2009/142/EC, GAD
- 2004/108/EC, EMC
- 2006/42/EC, MD
- 2006/95/EC, LVD

Standards:

- DIN 3362, EN 298
- EN 60730
- EN 1643, EN 525:2009

The relevant product corresponds to the type tested by the notified body 0085.

The production is subject to the surveillance procedure pursuant to Directive 2009/142/EC according to annex II paragraph 3.

Elster-Instromet B.V.

Scan of the Declaration of conformity (D, GB) – see www.docuthek.com

Goods return form

Name of the operator	
P.O. Box/Street	
Postcode and town/city	
Tel.	
E-mail	
Returned by (Mr./Ms.)	
Date	

Number of returns	
Heater serial number	
Power supply [V/Hz]	
Inlet pressure p_u [bar]	
Reasons for return	

Description of fault

Desired action	Credit note	Replacement	Repair
----------------	-------------	-------------	--------

Remarks

Date and signature	
--------------------	--

Please send returns back to your supplier.

Contact

If you have any technical questions, please contact your local branch office/agent. The addresses are available on the Internet or from Elster-Instromet B.V.

Munstermanstraat 6

7064 KA Silvolde

T +31 315 338-911

F +31 315 338-679

We reserve the right to make technical modifications in the interests of progress.

elster
Kromschröder

Elster-Instromet B.V.

Sales Office

Postfach 2809, 49018 Osnabrück

Strohteweg 1, 49504 Lotte (Büren)

Germany

T +49 541 1214 702

F +49 541 1214 506

orders.ermaf@elster.com, www.ermaf.com